VAKKA Quick Start ACTIVATION & **SETUP**

ACTIVATION



The two center wires are twisted together to turn the sensor on and then the protective tape seals the connection.



Twist wires together tightly with at least 3 turns or as many as possible.



Remove tape liner and center the foam tape over the connection



For a complete list of how-to guides scan the QR

code or visit us at: https://www.hgcr-technology.com/how-it-works ©HGCR Technology, LLC All Rights Reserved









Sign into VAKKA mobile application. Select your project from the menu. Select a sensor group or create a new one by clicking the "+" icon.





Click the "+" icon to

group. Enter sensor information and select "save sensor" Select sensor to display data

